
BATTERY-12V
MOTOR
M
Starting
switch
RELAY
Extinction
switch
flywheel
diode
charge
coil
Ignition
coil